



# ASSEMBLY SHEET FOR WINDSIGN WITH ALUMINUM BASE (PART # PWSM)

11450 STEPHENS RD  
WARREN, MI 48089  
800-682-7446  
www.tsscws.com

## CONTENTS



CROSS BAR

LEFT AND RIGHT LEGS

ALUMINUM BASE



FRAME WITH SPRINGS ATTACHED



BOLTS AND WASHER TO ATTACH  
SPRINGS TO BASE



**STEP 1** - REMOVE THE FRAME FROM THE BOX AND STAND THE FRAME AS SHOWN BELOW (USE THE BOX TO PREVENT SCRATCHING THE FRAME). PLACE THE CROSS BAR OVER THE TWO SPRINGS



**STEP 2** - PLACE THE LEFT AND RIGHT LEG OVER THE CROSS BAR (ALIGN THE HOLES WITH THE SPRINGS) SCREW BOLT AND WASHER INTO THE SPRINGS AND TIGHTEN.



**FINISHED PRODUCT**